# **Gas-Filled Radiation Detectors** Geiger-Mueller Tubes

Saint-Gobain Crystals offers a full-line of standard Geiger-Mueller detectors and probes. The design of a Geiger-Mueller tube is often optimized for a specific application; therefore, considerable differences in shape, size, gas formulations, and radiation sensitivity exist. Saint-Gobain Crystals has taken a proven technology forward to meet tomorrow's standards. Because today's Geiger-Mueller tubes need only simple electronics, are relatively rugged, and have low cost, they continue to be one of the most popular radiation detectors in use today.

Туре	Energy	Benefits
Plated	β, γ	Platinum lined cathodes increase the G-M tube's sensitivity. Commonly used in high temperature, high vibration applications such as oil well logging and density gauging.
Unplated	γ	Not as high-temperature, standard operating temperature is 75°C, not as sensitive.
Thin- walled	β, γ	Thin-wall GM tubes are machined to produce cathodes with very thin cross-sectional areas. This allows high energy beta particles to enter, making these particular tubes sensitive to both gamma and high energy beta particles.
End window	α, β, γ	The window built into these GM tubes allows beta particles and high energy alpha particles, as well as low dose gamma radiation, to enter the detector.
Pancakes	α, β, γ	The Pancake GM tube provides for a larger detection area compared to a regular cylindrical GM tube. In addition to gamma radiation, the large circular mica window allows for detection of beta particles and high energy alpha particles.





#### Applications -

Geiger-Mueller tubes provide effective means for both detecting and measuring the following types of radiation: Alpha particles, Beta particles, X-rays and Gamma rays.

Typical applications for Geiger-Mueller tubes include:

Personal Safety

- Body Frisking
- Survey Instruments
- Area Monitors

Recording Exposure Levels

- Digital Pocket Dosimeters
- Area Monitors
- Survey Instruments

Contamination Monitoring

- Area Monitors
  - Environmental Monitors
  - Stack Monitors

Non-destructive Density & Thickness Gauging

- Highway asphalt and concrete
- aggregate measurements
- On-line density or thickness
- monitoring in manufacturing

Gamma & Neutron-Gamma Oil Well Logging

# SAINT-GOBAIN

Geiger-Mueller Tubes - Typical Characteristics										
Drawing No.	Cathode Wall Thickness inches [mm]	Active Diameter inches [mm]	Active Length inches [mm]	Operating Voltage Range (V)	Operating Temperature Range (ºC)	Type of connector				
Plated										
s800-1241		0.61 [15.4]	2.45 [62.2]	650 - 800	-25 to 150	Flying Leads				
s800-1219			2.80 [71.1]	650 - 800		None				
s800-1220	]		2.80 [71.1]	650 - 800		Flying Leads				
s800-1210	]		4.33 [110.0]	850 - 1050		None				
s800-1209			4.33 [110.0]	850 - 1050		3-Pin				
s800-1262	]		4.56 [115.8]	850-1050		Flying Leads				
s800-1213			4.89 [124.2]	650 - 800		None				
s800-1214	]		4.89 [124.2]	650 - 800		Flying Leads				
s800-1215	0.01 [0.25]		6.92 [175.8]	650 - 800		None				
s800-1216			6.92 [175.8]	650 - 800		Flying Leads				
s800-1217			8.84 [224.5]	850 - 1050		Flying Leads				
s800-1218			8.84 [224.5]	850 - 1050		Cannon Plug				
s800-1212		0.73 [18.5]	4.86 [123.4]	850 - 1050	-25 to 150	3-Pin				
s800-1211			4.86 [123.4]	850 - 1050	-25 to 150	Flying Leads				
s800-1240			4.86 [123.4]	850 - 1050	-20 to 150	Lemo				
s800-1254			5.35 [135.9]	400 - 500	-20 to 150	None				
s800-1255			8.75 [222.3]	400 - 500	-25 to 150	None				
Unplated										
s800-1245	0.001 [0.05]	0.31 [7.8]	1.15 [29.2]	500 - 650	-40 to +75	Solder Clip				
s800-1224	0.01 [0.25]	0.57 [14.5]	1.34 [34]	450 - 650	-40 to +75	Solder Clip				
s800-1225	0.01 [0.25]	0.61 [15.4]	7.93 [201.4]	500 - 750	-40 to +100	3-pin				
s800-1227	0.01 [0.25]	.73 [18.4]	7.60 [193.0]	450 - 650	-40 to +100	Pins				
Unplated Thin walled										
s800-1229	0.002 [0.051]	0.61 [15.4]	8.69 [220.8]	850 - 1000	-20 to +150	Flying Leads				
s800-1230	0.002 [0.051]	0.61 [15.4]	8.71 [221.3]	850 - 1050	-20 to +150	None				
s800-1232	0.002 [0.051]	0.61 [15.4]	8.71 [221.3]	850 - 1050	-20 to +150	3-pin				
s800-1188	0.004 [ 0.102]	0.73 [18.4]	2.02 [51.3]	850 - 1000	-20 to +75	BNC				

Typical diameter: 0.625" [15.88] and 0.75" [19] Standard lengths up to 8.84" [225.5] active *Other sizes are possible* 

Geiger-Mueller Tubes - Typical Characteristics										
Drawing No.	Cathode Wall Thickness inches [mm]	Active Diameter inches [mm]	Active Length inches [mm]	Operating Voltage Range (V)	Operating Temperature Range (°C)	Type of connector				
Unplated End Window										
Steel 0.010"										
s800-1222	0.01 [0.25]	0.57 [14.5]	1.34 [34.0]	450 - 650	-40 to +75	Solder Clip				
<b>Mica</b> 2 mg/sq cm										
s800-1235	0.01 [0.25]	0.57 [14.5]	1.34 [34.0]	450 - 650	-40 to +75	Solder Clip				
s800-1236	0.06 [1.6]	1.125 [28.6]	2.46 [62.5]	850 - 950	-20 to +75	None				
s800-1237	0.06 [1.6]	1.125 [28.6]	2.46 [62.5]	850 - 950	-20 to +75	BNC Jack				
Pancake										
<b>Mica</b> 2 mg/sq cm										
s800-1192		1.75 [44.5]	0.5 [12.7]	850 - 1000	-55 to +75	Grid Cap				
s800-1193				475 - 675						





# Gas-Filled Radiation Detectors Geiger-Mueller Tubes

# SAINT-GOBAIN

#### USA

Saint-Gobain Crystals 17900 Great Lakes Parkway Hiram, OH 44234 Tel: (440) 834-5600 Fax: (440) 834-7680

#### Europe

Saint-Gobain Crystals 104 Route de Larchant BP 521 77794 Nemours Cedex, France Tel: 33 (1) 64 45 10 10 Fax: 33 (1) 64 45 10 01

P.O. Box 3093 3760 DB Soest The Netherlands Tel: 31 35 60 29 700 Fax: 31 35 60 29 214

#### Japan

**Saint-Gobain KK, Crystals Division** 3-7, Kojimachi, Chiyoda-ku, Tokyo 102-0083 Japan Tel: 81 (0) 3 3263 0559 Fax: 81 (0) 3 5212 2196

#### China

#### Saint-Gobain (China) Investment Co, Ltd

15-01 CITIC Building 19 Jianguomenwai Ave. Beijing 100004 China Tel: 86 (0) 10 6513 0311 Fax: 86 (0) 10 6512 9843

#### India

# Saint-Gobain Crystals and

Detectors Sy. No. 171/2, Maruthi Industrial Estate Hoody Rajapalya, Whitefield Main Road Bangalore 560048 India Tel: 91 80 42468989 Fax: 91 80 28416501

www.crystals.saint-gobain.com

## **Radiation Detected**

Geiger-Mueller (GM) tubes are typically designed to detect alpha, beta, and/or gamma radiation.

#### <sup>137</sup>Cs Photon Response

As a point of sensitivity reference, the photon response to a 1 mR/h<sup>137</sup>Cs (662 keV) field is given for all standard GM tubes listed. Energy compensated tubes have been designed for either an air KERMA response or an ambient dose equivalent response, both flat to better than +/-20%.

#### Maximum Shielded Background

This is the maximum permissible count rate resulting from a GM tube inside a lead chamber 2 inches thick, lined with aluminum.

# Suggested Operating Voltage (Figure 1)

The Suggested Operating Voltage generally appears in the center of the plateau. One can deviate from this suggestion as long as the applied voltage is still on the plateau.

#### Maximum Plateau Slope (Figure 1)

The GM tube Plateau Slope is defined as the percent change in sensitivity over a change in applied voltage. In this catalog, Plateau Slope is given by the percent change in sensitivity over 100 volts (%/100V).

#### **Maximum Dead Time**

Dead Time is the period of time a GM tube is insensitive to another counting event (expressed in microseconds).

## Maximum/Effective Length and Diameter

The Effective Length and Diameter are the sensitive portions of the GM tube cathode.

## Mica Window and Cathode Wall Density Thickness

Density thickness (mg/cm<sup>2</sup>) is a reference to the amount of radiation attenuating material for alpha and beta detection.

# **Starting Voltage**

The Starting Voltage is the lowest applied voltage at which a particular GM tube will produce a minimum count rate. Starting Voltage is dependent on the input threshold of a circuit and a chosen minimum count rate.

# Input Threshold

The Input Threshold or Discriminator limits the minimum pulse height to be counted. GM tubes produce relatively large voltage pulses compared to other types of radiation detectors. A typical threshold will be greater than 150 mV.



Manufacturer reserves the right to alter specifications. ©2014 Saint-Gobain Ceramics & Plastics, Inc. All rights reserved.